

PCoIP[®] Host Software for Windows User Guide

TER1008001

Issue 6



Teradici Corporation
#101-4621 Canada Way, Burnaby, BC V5G 4X8 Canada
p +1 604 451 5800 f +1 604 451 5818
www.teradici.com



The information contained in this document represents the current view of Teradici Corporation as of the date of publication. Because Teradici must respond to changing market conditions, it should not be interpreted to be a commitment on the part of Teradici, and Teradici cannot guarantee the accuracy of any information presented after the date of publication.

This document is for informational purposes only. TERADICI MAKES NO WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, AS TO THE INFORMATION IN THIS DOCUMENT.

Complying with all applicable copyright laws is the responsibility of the user. Without limiting the rights under copyright, no part of this document may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the express written permission of Teradici Corporation.

Teradici may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. Except as expressly provided in any written license agreement from Teradici, the furnishing of this document does not give you any license to these patents, trademarks, copyrights, or other intellectual property. Visit Teradici.com/patent for additional information.

© 2013 Teradici Corporation. All rights reserved.

Teradici, PC-over-IP, and PCoIP are registered trademarks of Teradici Corporation in the United States and/or other countries. The names of actual companies and products mentioned herein may be the trademarks of their respective owners.

Revision History

Version	Date	Description
6	March 04, 2013	Updated for release 4.0.10
5	September 05, 2012	Updated for release 4.0.8
4	August 13, 2012	Updated for release 4.0.7
3	February 17, 2012	Updated for release 3.5.20
2	February 4, 2011	Updated for release 3.3.20
1	August 26, 2010	Initial release

Contents

- Table of Figures 6
- 1 Introduction..... 9
 - 1.1 Audience 9
- 2 PCoIP Host Software..... 10
 - 2.1 System Requirements 11
 - 2.2 VMware View Soft Client Restrictions 12
 - 2.3 Release Notes 12
- 3 Installing PCoIP Host Software..... 13
 - 3.1 Enabling the Host Driver Function 13
 - 3.2 Installing PCoIP Host Software..... 14
- 4 Uninstalling PCoIP Host Software 20
 - 4.1 Uninstalling the PCoIP Host Software for Windows 20
 - 4.2 Disabling Host Driver Function 20
- 5 Using the PCoIP UI 21
 - 5.1 Features..... 22
 - 5.2 Network..... 26
 - 5.3 Statistics..... 28
 - 5.4 Monitors 29
 - 5.5 Image 31
 - 5.6 About..... 32
- 6 Troubleshooting..... 34
 - 6.1 Debug Logs..... 38
 - 6.2 Requirements for Local Cursor and Keyboard Feature..... 39
 - 6.3 Requirements for Using the Client Display Topology 40
 - 6.4 Tested System Configurations..... 40

