

8216 Switch Settings

Left Group of Switches		
Switch	Position	Action
L1		Reserved for future use
1L2	Down	Form Feed by ASCII FF (OC) when possible
L3	Down	All data sent to printer, narrow carriage printers will continue printing on next line.
	Up	All data beyond 8 inches is truncated
L4	Down	Normal operation
	Up	EBCDIC Hexadecimal print of host data

Right Group of Switches		
Switch	Position	Action
R1	Down	Normal
	Up	Self Test Mode
Switch	Switch	Emulation Mode
R2	R3	
Down	Down	5256 Emulation
Down	Up	5224 Emulation (no LAC Support)
UP	Down	5225 Emulation (no LAC Support)
Up	Up	Test Modes
Switch	Switch	LPI/CPI Control
<u>R4</u>	<u>R5</u>	
Down	Down	No LPI/CPI Control
Down	Up	Proprinter LPI / CPI codes
UP	Down	Epson FX (9pin) LPI / CPI codes
Up	Up	Epson LQ (24 pin) LPI/CPI codes

Right Group of Switches			
Switch	Switch	Switch	Cable Address
<u>R6</u>	<u>R7</u>	<u>R8</u>	
Down	Down	Down	0
Down	Down	UP	1
Down	UP	Down	2
Down	UP	UP	3
UP	Down	Down	4
UP	Down	UP	5
UP	UP	Down	6
UP	UP	UP	Test Modes