

I-O 8300 Switch Settings

Table 2-2 Switch Settings, (Group of Four Switches)

Printer Model	Printer Head	Carriage Size	Switch 1	Switch 2
EX-800	9-Pin	10"	OFF	ON
FX-86e	9-Pin	10"	OFF	ON
FX-850	9-Pin	10"	OFF OFF	ON
EX-1000	9-Pin	16"	ON	ON
FX-286e	9-Pin	16"	ON	ON
FX-1050	9-Pin	16"	ON	ON
DFX-5000	9-Pin	16"	ON	ON
DFX-8000	9-Pin	16"	ON	ON
LQ-500	24-Pin	10"	OFF	OFF
LQ-510	24-Pin	10"	OFF	OFF
LQ-850	24-Pin	10"	OFF	OFF
LQ-950	24-Pin	12"	OFF	OFF
LQ-800	24-Pin	16"	ON	OFF
LQ-810	24-Pin	16"	ON	OFF
LQ-1050	24-Pin	16"	ON	OFF
LQ-2500	24-Pin	16"	ON	OFF
LQ-2550	24-Pin	16"	ON	OFF
EPL-7100	Laser	8.5"	OFF	OFF
EPL-7500	Laser	8.5"	OFF	OFF

Mode	Switch 3	Switch 4
Normal Operation	OFF	OFF
Self Test	ON	OFF
EBCDIC Hex Print	OFF	ON

Table 2-1 Switch Settings, (Group of Eight Switches)

Emulation	Switch 1
4214 / 5224	OFF
5219 / 3812	ON

Address	Switch 2	Switch 3	Switch 4
0	OFF	OFF	OFF
1	OFF	OFF	ON
2	OFF	ON	OFF
3	OFF	ON	ON
4	ON	OFF	OFF
5	ON	OFF	ON
6	ON	ON	OFF
7	ON	ON	ON

Language	Switch 5	Switch 6	Switch 7	Switch 8
Multinational	OFF	OFF	OFF	OFF
USA / Canada	OFF	OFF	OFF	ON
Austria / German	OFF	OFF	ON	OFF
Belgium	OFF	OFF	ON	ON
Brazil	OFF	ON	OFF	OFF
Canada / French	OFF	ON	OFF	ON
Denmark / Norway	OFF	ON	ON	OFF
Finland / Sweden	OFF	ON	ON	ON
France	ON	OFF	OFF	OFF
Italy	ON	OFF	OFF	ON
Japan	ON	OFF	ON	OFF
Japan (English)	ON	OFF	ON	ON
Portugal	ON	ON	OFF	OFF
Spain	ON	ON	OFF	ON
Spanish Speaking	ON	ON	ON	OFF
United Kingdom	ON	ON	ON	ON